




decoflame® Orlando Manual 800 Open front and back
1000x400x300mm, Black Frame 50x5mm Black
 1x 110mm low glass Front and 1x full glass Back
 Wall cut-out "1010x410x296mm"




Dimensions are in millimeters		 DecoFlame ApS Vang Mark 2 9380 Vestbjerg TLF: +45 96 30 48 00 www.decoflame.com	SCALE: 1:10
REVISION:	Date		FORMAT: A3
-	27-04-2020		Page 1 OF 4
Author: TTK		Order Number - Customer - Reference: PRINCIPLE Orlando Front and Back - conv. 1000x400x300mm - 1x MB800 - low high glass	
Copyright of DecoFlame ApS Denmark, whose property this document remains. No part thereof may be disclosed, copied, duplicated or in any other way made use of, except with the approval of DecoFlame ApS.		Customer Approval Signature - Date	

Orlando - Open to front and back




SECTION AS-AS
SCALE 1 : 10



DETAIL AU
SCALE 1 : 5

MB: Manuel Burner
DB: Electrical burner (Denver Basic)

Wall cut-out dimensions




NOTE

It is possible to change the burner unit, if you want to upgrade your fireplace from a manuel burner to an electrical burner

If only a manual burner is required, the recess is: W=150mm D=70mm
By changing from manuel burner to electrical burner, the recess is: W=210mm D=150mm




View without Frames



DETAIL AT
SCALE 1 : 2

Dimensions are in millimeters		 DecoFlame ApS Vang Mark 2 9380 Vestbjerg TLF: +45 96 30 48 00 www.decoflame.com	SCALE: 1:12
REVISION: -	Date: 27-04-2020		FORMAT: A3
Author: TTK		Order Number - Customer - Reference:	Page 2 OF 4
Copyright of DecoFlame ApS Denmark, whose property this document remains. No part thereof may be disclosed, copied, duplicated or in any other way made use of, except with the approval of DecoFlame ApS.		PRINCIPLE Orlando Front and Back - conv. 1000x400x300mm - 1x MB800 - low high glass	
		Customer Approval Signature - Date	

View without frame



Orlando - Open to front and back

General Installation Guidelines for "decoflame® made to measure fireplaces", open to two sides:

It is essential to maintain a 5mm gap all the way around the fireplace (Cut-out = Fireplace Dimensions + 10mm) This gap must not be sealed.

As the edges of the cut-out remain visible it is important that they are done to the highest possible finish. All four corners of the cut out must have exactly a 90 degree angle.

Plasterboard walls - Stud-walls

All surfaces inside the wall cut-out are to be covered with fibre plaster sheets or other non-inflammable materials.


Stone/Brick walls

The cut-out is made according to the attached drawing.

Important

Make sure to create a closed cavity for the section below the base plate of the fire and above the roof of the fireplace.

Installation process




Exploded view showing the installation process.

1. The casing with glassholders, frame back and glass high back is centered in the wall cut out.
 - the casing secured with fasteners and use suited wall plugs.
2. Connect the burner to power socket and placed in the safety chamber.
3. Frame front secured carefully, then finally placed the low glass.


REVISION: -		Date: 27-04-2020	 DecoFlame ApS Vang Mark 2 9380 Vestbjerg TLF: +45 96 30 48 00 www.decoflame.com	SCALE: 1:10
Author: TTK		Order Number - Customer - Reference: PRINCIPLE Orlando Front and Back - conv. 1000x400x300mm - 1x MB800 - low high glass		FORMAT: A3
Copyright of DecoFlame ApS Denmark, whose property this document remains. No part thereof may be disclosed, copied, duplicated or in any other way made use of, except with the approval of DecoFlame ApS.			Customer Approval Signature - Date	Page 3 OF 4

IMPORTANT INFORMATION


Particulars of the wall in which the fireplace shall be installed



DO NOT! install the fireplace in a wall construction which is open above and below the fireplace. The warm air will cause turbulences inside this hollow construction which will have a negative impact on the flames.



DO! install the fireplace in an open-wall construction, which is closed above and below the fireplace. Make sure to create a closed cavity for the section below the base plate of the fire.



DO! install the fireplace in a massive wall (made of bricks, stone or gas beton) using the wall cut-out dimensions mentioned on the previous page.

Dimensions are in millimeters		 DecoFlame ApS Vang Mark 2 9380 Vestbjerg TLF: +45 96 30 48 00 www.decoflame.com	SCALE: 1:10
REVISION: -	Date 27-04-2020		FORMAT: A3
Author: TTK		Order Number - Customer - Reference:	Page 4 OF 4
Copyright of DecoFlame ApS Denmark, whose property this document remains. No part thereof may be disclosed, copied, duplicated or in any other way made use of, except with the approval of DecoFlame ApS.		PRINCIPLE Orlando Front and Back - conv. 1000x400x300mm - 1x MB800 - low high glass	Customer Approval Signature - Date